



1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc.
2. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with a 6" (152 mm) strip of Uncured EPDM Flashing, or 7" (178 mm) Peel & Stick. See Detail E-3.01.
3. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner. Then apply GenFlex Primer.

MAXIMUM WARRANTY: **10 Years**



**Continuous Membrane Base Flashing - Horizontally Secured**

EPDM Systems

ACCEPTABLE SYSTEMS:  
Fully Adhered & Mechanically Attached

ISSUE / REVISION  
DATE:  
6-22-2015

NOT TO SCALE

DETAIL NO.

**E-2.04**