



1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc.
2. When using a GenFlex Peel & Stick Corner, apply a high profile bead of GenFlex Edge Caulk on the outside edge of the completed seam.
3. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner, then apply GenFlex Primer.



**Peel & Stick Outside Corner**

EPDM Systems

ACCEPTABLE SYSTEMS:  
All Systems

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION  
DATE:  
6-24-2015

NOT TO SCALE

DETAIL NO.

**E-5.03**