



1. GenFlex EZ TPO Peel & Stick RMA must be fastened along the entire length of both structural purlins located closest to the ridge.
2. Prime the backside of the TPO membrane with Clear Primer prior to attaching to the RMA strip.
3. GenFast Purlin Fasteners must penetrate the structural purlin a minimum of 1.5" (38 mm) total.
4. If structural purlins are spaced every 5' (1.5 m), fastener spacing is not to exceed 12" (305 mm) o.c. If structural purlins are spaced every 6' (1.8 m), fastener spacing is not to exceed 6" (152 mm) o.c.



EZ TPO Systems

**Ridge Attachment**

ACCEPTABLE SYSTEMS:  
Metal Building Recover

MAXIMUM WARRANTY: **15 Years**

ISSUE / REVISION  
DATE:  
10-27-2015

DETAIL NO.  
**EZ-S-19.05**

NOT TO SCALE