



FIRST PANEL APPLICATION

1. Position the GenFlex TPO Peel & Stick™ membrane over the approved substrate without stretching.
2. Unroll 20' - 30' of the Peel & Stick™ panel at the starting point of the roof with the selvage edge on the downslope side of the roll to facilitate proper lapping of the seams (shingle lapped).
3. Fold 10' - 15' of the panel back upon itself exposing the release liner. The portion of the unrolled panel left after folding back 10' - 15' is intended to help keep the panel aligned with the original layout position.
4. Peel the release liner from the adhesive film back to the point of membrane fold and lay to the side of the panel (do not cut release liner).
5. Roll the membrane with the exposed adhesive onto the GenFlex approved substrate inline with the original layout position. Maintain a smooth radius to the roll when rolling out to avoid creating wrinkles.
6. Using a stiff bristle broom and positive downward pressure, broom in the installed section of Peel & Stick™ membrane. This installed area will be the anchor point and alignment guide for the installation of the remainder of the roll. Brooming direction should be across the short axis of the panel to avoid creating wrinkles in the sheet.
7. Roll the Peel & Stick™ membrane back to the point that the release liner becomes accessible and peel the release liner from the adhesive film as the roll travels along the installation path.
8. Using a stiff bristle broom and positive downward pressure, broom in the installed Peel & Stick™ membrane. Brooming direction should be across the short axis of the panel to avoid creating wrinkles in the sheet.

Proceed with the appropriate installation method for your installation detailed below.

This detail is specifically intended for first roll application because of the alignment control this method provides, however, this method may be used throughout the roof system if desired. This is the only suitable detail for use in multiple rolling applications due to the alignment requirements involved with such an operation.

GenFlex
Roofing Systems

03/03

First Panel Installation

Detail #: PS-16.01

Peel & Stick™ TPO Systems