



During a multiple roll application all seams must be shingled in the direction of water flow. Special attention is required to properly align, and maintain alignment of the GenFlex Peel & Stick™ TPO rolls during application. Refer to detail PS-16.02 Membrane Installation - Scroll Method for guidance.