



1. Do not install over field seams or bar cover tape.
2. Extend 2" (51 mm) beyond wood support in all directions.
3. Use caution to prevent punctures in membrane.