



1. All wood nailers to be approved material. Attachment of wood nailer to be accomplished by using fasteners providing no less than 125 lb (556 N) of pullout. Fasteners shall be spaced no greater than 12" o.c. (305 mm).
2. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner, then apply GenFlex Primer.
3. Polymer batten strips cannot be used for attachment into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.
4. Tie-In must be acceptable with existing membrane manufacturer.
5. Tie-In must be with compatible material.



EPDM Systems Tie-In

EPDM Systems

ACCEPTABLE SYSTEMS:
Fully Adhered & Mechanically Attached

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION
DATE:
6-25-2015

NOT TO SCALE

DETAIL NO.

E-18.01