



1. When using GenFlex FlexWhite Seam Tape, first apply FlexWhite Clear Primer to the seaming area using a GenFlex Scrub Pad & Handle. Primer is required on both membrane surfaces to which the seam tape will bond.
2. Apply GenFlex FlexWhite Edge Caulk around entire perimeter of GenFlex FlexWhite Peel & Stick T-Joint Cover and along seams for 6" (152 mm) past intersection.



**T-Joint/Seam Intersection Cover**

EPDM Systems

ACCEPTABLE SYSTEMS:  
Fully Adhered

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION  
DATE:  
6-25-2015

NOT TO SCALE

DETAIL NO.  
**FW-6.10**