



1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc. and be primed with GenFlex Clear Primer.
2. Polymer batten strips cannot be used for attachments into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.
3. Apply GenFlex EZ TPO Edge Caulk to all seam and flashing edges.

Refer to detail PS-6.01 for seaming options.

MAXIMUM WARRANTY: **20 Years**



**Inside Corner Flashing with TPO Flashing Kit Material**

EZ TPO Systems

ACCEPTABLE SYSTEMS:  
Self Adhered

ISSUE / REVISION  
DATE:  
10-26-2015

DETAIL NO.  
**EZ-S-4.02**

NOT TO SCALE